


FRONT




LEFT FRONT



RIGHT FRONT



BACK



BACK RIGHT

A1-6...BI-TORQ ACTUATOR, PN52SR
 WITH OASIS BALL VALVE, BV704
 BV1,2...PARKER 1/2" BALL 62 SERIES VALVE
 BVD1,2...PARKER BALL VALVE, PFG-4M-BV-4SSG
 CIB....TGT CUSTOMER INTERFACE BOARD
 CV1-6...OASIS CHECK VALVE 1/2", CV204
 CV7.....OASIS CHECK VALVE 1/4", CV102
 F1,2,3..FILTER, TGT-A-8519C-N.3MA-BS6
 M1,2...METER, MICRO MOTION SENSOR
 MM-XNG50A29ONCAAEZZZ
 TRANSMITTER MM-2700IA3ABEZZZ

NV1-4...NEEDLE VALVE, NOSHOK, 152MCF
 PSIG1...ASHCROFT 0-200 GAUGE
 PS1,2...ENERGY KINETICS PRESSURE SENSOR,
 EK-109-1/PE
 PT1,2...WIKA PRESSURE TRANSMITTER, 50608665
 R1.....REGULATOR, BELGAS P39
 RV1,2...TAYLER RELIEF VALVE, SERIES 8100
 S1-6....SOLENOID VALVE, PETER PAUL ELEC. CO.
 E23Z0109LCCM




NZ

3WV


PSIG



BB



DB




CIB




VLB

ILB



AND

MMI



MB

- AND....ALPHA-NUMERIC DISPLAY,
4 LINE X 40 CHAR., DCI404AF3BW6
- BB....TGT BREAKAWAY BASE
- CIB....CUSTOMER INTERFACE BOARD,
TGT 23005
- DB....DISPLAY BOARD, 23002
- ILB....TGT-6ILB IN-LINE BREAKAWAY
- MMI....MAN-MACHINE INTERFACE BOARD, TGT
23007
- MB....MAIN BOARD, TGT 23004
- NZ....STAUBLI NOZZLE, N2